

Hochlastzeitfenster Strom

für Genehmigungszeitraum

2025 (Basis: 01.09.2024 - 31.08.2025)

Netz- / Umspannebene der Entnahme	Herbst (Sept.-Nov.)		Winter (Dez.-Feb.)		Frühling (März-Mai)		Sommer (Juni-Aug.)	
	Startpunkt	Endpunkt	Startpunkt	Endpunkt	Startpunkt	Endpunkt	Startpunkt	Endpunkt
Netzebene Mittelspannung	05:45	06:00	06:45	07:00			08:30	08:45
	09:45	10:30					10:00	10:15
	21:30	22:00					10:30	10:45
							11:15	11:30
Netzebene Umspannung MS/NS	06:45	07:00	01:00	01:30	07:00	07:15	02:15	02:45
			04:45	05:15	08:30	08:45	05:45	06:45
			08:15	08:30	09:30	09:45	07:45	08:00
			09:00	09:45	10:45	12:00	10:00	10:30
			19:30	19:45	23:30	00:00	10:45	11:00
							21:30	21:45
Netzebene Niederspannung							07:45	08:30
							09:00	12:45